


Kress



KUS35P



Posición	Referencia	Cantidad	Descripción
1	60066455	1	Outer Flange
3	60066457	1	Inner Flange
4	60067504	1	Guard
5	60066459	1	Screw M8X25
6	60066460	1	Spindle
7	60066461	1	Woodruff Key
8	60066462	1	Dust Cover
9	60066463	2	Screw M5X16
10	60066464	2	Screw M5X25
11	60066465	1	Fore Cover
12	60066466	1	O-Ring
13	60066467	1	Bearing6203-2Rs
14	60066468	1	Press Plate
15	60066469	7	Screw M4X12
16	60067505	1	Main Gear
17	60066471	1	Retaining Ring
18	60066472	1	Bearing 609-2Z
20	60066474	1	Gear Housing
21	60066475	4	Self Tapping Screw ST4.8X40
22	60066476	1	Spindle Lock Cap
23	60066477	1	Compression Spring
24	60066478	1	O-Ring
25	60066479	1	Retaining Ring
26	60066480	1	Nut
27	60067506	1	Pinion
28	60066482	1	Oil Washer
29	60066483	1	Bearing 6301-2Rs
30	60066484	1	Bearing Gland
31	60066485	1	Dust-Proof Cushion
32	60066486	1	Rotor
33	60066487	1	Dust Proof Ring
34	60066488	1	Bearing 6000-2Rz
35	60066489	1	Bearing Sleeve
36	60066490	1	Wind Baffle Ring
37	60066491	2	Self Tapping Screw ST4.8X75
38	60066492	1	Stator
39	60066493	1	Left/Right Carbon Brush Cover

Posición	Referencia	Cantidad	Descripción
40	60066494	1	Housing
41	60066495	5	Self Tapping Screw ST4.2X12
43	60066496	1	Carbon Brush(Pair)
44	60066497	2	Spiral Spring
45	60066498	2	Brush Holder Assembly
46	60066499	1	Left/Right Handle
47	60066500	1	Capacitance
48	60066501	1	Switch
49	60066502	4	Self Tapping Screw ST4.2X16
51	60066503	1	Cable Clamp
52	60066504	1	Cord Protector
53	60067507	1	Power Cord
54	60066506	1	Spanner
55	60066507	1	Auxiliary Handle
56	60066508	1	Allen Key
57	60067509	1	Soft Start
101	60066509	1	Gear Housing Assembly
102	60066510	1	Front Cover Assembly
103	60066511	1	Rotor Assembly