

Kress

KUD12.9



Spare parts list





Model	Position	Part number	Description	Quantity
KUD12.9	1	59004148	Spanner	1
KUD12.9	2	59004147	Ornament Cover I+II	1
KUD12.9	3	59001302	Guide Pin	2
KUD12.9	5	59000512	Cylindrical Pin	2
KUD12.9	6	59001304	Support	1
KUD12.9	9	59004149	Spanner Base	1
KUD12.9	10	59004150	Retaining ring	1
KUD12.9	11	59000079	Screw	4
KUD12.9	12	59001327	Compression Block	1
KUD12.9	13	59001318	Spring Board	1
KUD12.9	14	59001207	Self Tapping Screw ST3.9*30	4
KUD12.9	15	59001047	Spring washer	4
KUD12.9	16	59004031	Ornament Cover	1
KUD12.9	17	59001315	Compression Spring	1
KUD12.9	18	59001354	Lock Nut	1
KUD12.9	31	59001305	Flange Assembly	1
KUD12.9	32	59001350	Retaining ring	1
KUD12.9	33	59004012	Ball Bearing	1
KUD12.9	34	59001322	Washer	1
KUD12.9	35	59004020	Counterweight	1
KUD12.9	36	59004036	O-ring	1
KUD12.9	37	59004026	Middle Cover	1
KUD12.9	38	59000472	Washer	1
KUD12.9	39	59004022	Fan	1
KUD12.9	40	59004021	Rotor	1
KUD12.9	41	59004016	Washer	1
KUD12.9	42	59004010	Ball Bearing	1
KUD12.9	43	59004033	Guide Ring	1
KUD12.9	44	59004025	Self Tapping Screw 2.9X23	2
KUD12.9	46	59004024	Stator	1
KUD12.9	48	59004035	Left Housing	1
KUD12.9	50	59004030	Chuck Ring	1
KUD12.9	51	59004007	Switch button	1
KUD12.9	53	59004029	Power Supply Board	1
KUD12.9	54	59004011	Throttle Plate Gasket	1
KUD12.9	55	59000508	Washer	1
KUD12.9	56	59004023	Right Housing	1
KUD12.9	57	59000002	Self Tapping Screw ST3.9x16	6
KUD12.9	58	59004032	LED Board Assembly	1
KUD12.9	61	59004141	Sanding Pad Perforated	1
KUD12.9	62	59004038	Press Bolt	1
KUD12.9	63	59004028	Rubber Pin	4
KUD12.9	64	59004034	Screw	3
KUD12.9	101	59004027	Lock Lever Assembly	1
KUD12.9	102	59004018	Fore Housing Assembly	1
KUD12.9	103	59004151	Rotor Set	1

Oscillation Tool 20V BL 3° Oscillation Angle

Version:00
Date:221102

Illustr

Electric circuit



ation

