

## Spare parts list

Model	Position	Part number	Description	Quantity
KH177	1	59001791	Decorative cover	1
KH177	2	59007790	Gear changing lever	1
KH177	3	59007797	Screw M3x8	1
KH177	4	59007752	Hook	1
KH177	6	59007798	Left/right housing	1
KH177	7	59008151	Light cover	1
KH177	8	59007794	F R button	1
KH177	9	59007791	Screw M5x20	1
KH177	10	59005636	Chuck	1
KH177	11	59007799	Gear case assembly	1
KH177	14	59007789	Stator	1
KH177	15	59007788	Rear cover	1
KH177	16	59007480	Screw ST2.9x16	9
KH177	17	59000863	Spring lock	2
KH177	18	59007792	Control board	1
KH177	19	59008152	Switch	1
KH177	20	59001950	Battery Pack(Li-ion,2.0Ah,12V)KPB1202	2
KH177	23	59001951	Charger(110-240V,12V,22W)KCH1202	1
KH177	24	59001807	Foamy Board	1
KH177	25	59007795	Support base set	1
KH177	101	59008153	Rotor set	1

# Kress

## KH177H



Illustration

