

Spare parts list

Model	Position	Part number	Description	Quantity	Model	Position	Part number	Description	Quantity
KH382.91	1	59000488	Dustproof Cover	1	KH382.91	61	59000528	Rubber sleeve	1
KH382.91	2	59001983	Clamping ring	1	KH382.91	62	59000507	Felt Seal	2
KH382.91	3	59000948	Fence	1	KH382.91	63	59000495	E Ring	1
KH382.91	4	59000945	Slide sleeve	1	KH382.91	64	59000651	Pendulum Fork	1
KH382.91	5	59000946	Sheath	1	KH382.91	65	59000454	Washer	1
KH382.91	6	59000947	Sheath	1	KH382.91	66	59002378	Bearing	1
KH382.91	7	59000453	Steel ball	1	KH382.91	67	59000481	Bearing press plate	1
KH382.91	8	59000382	Baffle plate	1	KH382.91	68	59001778	Self Tapping Screw M4*10	2
KH382.91	9	59008444	Compression spring	1	KH382.91	69	59008446	Rotor	1
KH382.91	10	59000489	Ring	1	KH382.91	70	59000478	E ring	1
KH382.91	11	59008453	Box cover	1	KH382.91	71	59008448	Eccentric	1
KH382.91	13	59000499	Oil Seal	1	KH382.91	72	59000537	Compression spring	1
KH382.91	14	59000459	Washer	1	KH382.91	73	59000464	Retaining ring	1
KH382.91	15	59000376	Ball Bearing 61804	1	KH382.91	74	59000503	Needle bearing	1
KH382.91	16	59008461	Washer	1	KH382.91	75	59008460	Clutch lining	1
KH382.91	17	59000543	Washer	1	KH382.91	76	59000472	Washer	1
KH382.91	18	59000638	Locking plate	1	KH382.91	77	59000648	Gear 2	1
KH382.91	19	59000539	Screw ST2.9x8	1	KH382.91	78	59000476	Retaining Ring	1
KH382.91	20	59004992	Press plate	1	KH382.91	79	59008452	Bearing 61800-2RS	1
KH382.91	21	59000542	Compression spring	2	KH382.91	80	59000447	Washer	1
KH382.91	22	59000465	Flet Plug	1	KH382.91	81	59008449	Washer	1
KH382.91	23	59000450	Rubber cushion	1	KH382.91	82	59000521	Baffle	1
KH382.91	24	59000520	Seal ring	1	KH382.91	83	59000523	Washer	2
KH382.91	25	59008442	Cover	1	KH382.91	84	59008455	Stator	1
KH382.91	26	59000484	Self Tapping Screw	8	KH382.91	85	59001943	Holding Cover	1
KH382.91	27	59000518	O Ring	1	KH382.91	86	59000463	Left/right housing	1
KH382.91	28	59000480	Slide Button	1	KH382.91	87	59000514	Self Tapping Screw	4
KH382.91	29	59004984	Compression Spring	2	KH382.91	88	59008450	Control board	1
KH382.91	30	59000516	Knob	1	KH382.91	89	59000452	Self Tapping Screw	8
KH382.91	31	59008600	Sleeve	1	KH382.91	90	59008447	Handle	1
KH382.91	32	59000457	O ring	2	KH382.91	91	59000367	F/R change lever	1
KH382.91	33	59008601	Striker pin	1	KH382.91	92	59000508	Washer	1
KH382.91	34	59000647	Holding cover 2	1	KH382.91	93	59000451	Rubber Column	2
KH382.91	35	59000545	Anti Vibration Gasket	1	KH382.91	94	59008603	Label	1
KH382.91	36	59000642	Holding cover 1	1	KH382.91	95	59008604	Button set	1
KH382.91	37	59000473	Circlip	1	KH382.91	96	59008458	Rubber sheath	1
KH382.91	38	59008602	Ram	1	KH382.91	98	59007846	Base holder	1
KH382.91	39	59008441	O ring	2	KH382.91	99	59007850	Dustproof cover	1
KH382.91	40	59000497	Ball Bearing	1	KH382.91	102	59008457	Side handle	1
KH382.91	41	59000644	Bearing press plate	1	KH382.91	103	59001203	Foamy Board	2
KH382.91	42	59000847	Conic Gear	1	KH382.91	105	59006465	Switch	1
KH382.91	43	59000471	Cylindrical Pin	1	KH382.91	201	59008611	Gear case assembly	1
KH382.91	44	59000548	Clamping ring	1	KH382.91	202	59008605	Sleeve set	1
KH382.91	45	59000533	Washer	1	KH382.91	203	59008608	Clutch sleeve 2 assembly	1
KH382.91	46	59000509	Torsion spring support plate	1	KH382.91	204	59000850	Middle Shaft I Assembly	1
KH382.91	47	59000534	Different torsional spring	1	KH382.91	205	59008606	Middle cover set	1
KH382.91	48	59000646	Clutch sleeve 2	1	KH382.91	206	59008607	Rotor set	1
KH382.91	49	59008443	Piston	1	KH382.91	207	59008609	Eccentric assembly	1
KH382.91	50	59000659	Piston pin	1	KH382.91	208	59008610	Stopples assembly	1
KH382.91	51	59000475	Linkage	1	KH382.91		59008629	Foamy board	1
KH382.91	52	59001569	Gear Shaft I	1					
KH382.91	53	59000456	Ball Bearing 608	1					
KH382.91	54	59000506	Washer	1					
KH382.91	55	59001570	Gear 1	1					
KH382.91	56	59000522	Seal gasket	1					
KH382.91	57	59000653	Pin shaft	1					
KH382.91	58	59002862	Bearing	2					
KH382.91	59	59000652	Middle cover	1					
KH382.91	60	59000500	Oil Seal	1					

Kress

KH382.91



Illustration

