

## Spare parts list

Model	Position	Part number	Description	Quantity
KH277.91	1	59008651	Decorative sleeve	1
KH277.91	2	59008644	Fore housing body	1
KH277.91	4	59008632	Washer	1
KH277.91	7	59008658	Spindle set	1
KH277.91	8	59008641	O ring	1
KH277.91	9	59001453	Steel ball	1
KH277.91	16	59008636	Ring	1
KH277.91	17	59008648	O ring	1
KH277.91	18	59008642	inner gear ring	1
KH277.91	19	59008643	Planetary gear	3
KH277.91	20	59008634	Pin	3
KH277.91	21	59008633	Bearing 6806-2RS	1
KH277.91	22	59008653	Cover	1
KH277.91	23	59000738	O Ring	1
KH277.91	24	59008649	Screw M5x35	4
KH277.91	25	59008646	Rotor	1
KH277.91	26	59008654	Stator	1
KH277.91	27	59008630	Cover	1
KH277.91	28	59000452	Self Tapping Screw	11
KH277.91	29	59008659	Label	1
KH277.91	30	59000451	Rubber Column	2
KH277.91	32	59008645	F R button	1
KH277.91	33	59003691	Rubber pin	4
KH277.91	34	59008652	Left/right housing	1
KH277.91	36	59004056	Switch	1
KH277.91	40	59005700	Screw M5x10	2
KH277.91	41	59008635	Hanging ring base	1
KH277.91	42	59008640	Hanging ring	1
KH277.91	43	59000508	Washer	1
KH277.91	47	59008647	Washer	1
KH277.91	48	59008660	Hall PCB	1
KH277.91	51	59008639	Spanner	1
KH277.91	101	59008661	Gear case set	1
KH277.91	102	59008637	Driving shaft	1
KH277.91	103	59008638	Control board	1

# Kress

## KH277.91



Illustration

