

## Spare parts list

Model	Position	Part number	Description	Quantity
KH177M	1	59001791	Decorative cover	1
KH177M	2	59007790	Gear changing lever	1
KH177M	3	59007797	Screw M3x8	1
KH177M	4	59007752	Hook	1
KH177M	6	59007798	Left/right housing	1
KH177M	7	59008151	Light cover	1
KH177M	8	59007794	F R button	1
KH177M	11	59009509	Gearbox	1
KH177M	14	59007789	Stator	1
KH177M	15	59007788	Gear cover	1
KH177M	16	59007480	Screw ST2.9x16	9
KH177M	17	59000863	Spring lock	2
KH177M	18	59007792	Control board	1
KH177M	19	59008152	Switch	1
KH177M	20	59001950	Battery Pack(Li-ion,2.0Ah,12V)KPB1202	2
KH177M	20	59002560	Battery Pack(Li-ion,2.0Ah,12V)KPB1202	2
KH177M	23	59002561	Charger(110-240V,12V,22W)KCH1202	1
KH177M	23	59001951	Charger(110-240V,12V,22W)KCH1202	1
KH177M	24	59001807	Foamy Board	1
KH177M	25	59007795	Support base set	1
KH177M	26	59009510	Drill chuck	1
KH177M	27	59009508	Drill chuck	1
KH177M	28	59009511	Drill chuck	1
KH177M	29	59009506	Drill chuck	1
KH177M	101	59009536	Rotor set	1

# Kress



## KH177M



Illustration

