

Spare parts list

Model	Position	Part number	Description	Quantity	Model	Position	Part number	Description	Quantity
KH325P	1	60081876	Cap	1	KH325P	62	60081935	Gear shaft	1
KH325P	2	60081877	Ring spring	1	KH325P	63	60081936	Clutch spring	1
KH325P	3	60081878	Washer	1	KH325P	64	60081937	Clutch spring seat	1
KH325P	4	60081879	Ring spring	1	KH325P	65	60081938	Washer	2
KH325P	5	60081880	Chuck cover	1	KH325P	66	60081939	Clutch spring seat(iron)	1
KH325P	6	60081881	Iron ring	1	KH325P	67	60081940	Rubber pad	1
KH325P	7	60081882	Steel ball	1	KH325P	68	60081941	Plastic fork	1
KH325P	8	60081883	Gasket	1	KH325P	69	60081942	Ring spring	1
KH325P	9	60081884	Spring	1	KH325P	70	60081943	Skeleton oil seal	1
KH325P	10	60081885	Sleeve	1	KH325P	71	60081944	Bearing 629	1
KH325P	11	60081886	Pin	4	KH325P	72	60081945	609 bearing gland	1
KH325P	12	60081887	O ring	1	KH325P	73	60081946	Screw M4x8	2
KH325P	13	60081888	Oil seal	1	KH325P	74	60081947	Retaining ring	1
KH325P	14	60081889	Sleeve	1	KH325P	75	60081948	Armature	1
KH325P	15	60081890	Impact bolt	1	KH325P	76	60081949	Dust proof ring	1
KH325P	16	60081891	Gear box	1	KH325P	77	60081950	Bearing 607	1
KH325P	17	60081892	Oil seal	1	KH325P	78	60081951	Bearing housing 607	1
KH325P	18	60081893	Needle bearing HK3012	1	KH325P	79	60081952	Guide ring	1
KH325P	19	60081894	Sleeve	1	KH325P	80	60081953	Screw ST4.2x16	2
KH325P	20	60081895	Washer	1	KH325P	81	60081954	Stator	1
KH325P	21	60081896	Ring spring	1	KH325P	83	60081955	Sticker	1
KH325P	22	60081897	Washer	1	KH325P	84	60081956	Housing	1
KH325P	23	60081898	Spring	1	KH325P	85	60081957	Screw ST4.5x42	4
KH325P	24	60081899	Big gear	1	KH325P	86	60081958	Semicircular shrapnel	2
KH325P	25	60081900	Cylinder	1	KH325P	87	60081959	Screw ST4.2x14	2
KH325P	26	60081901	Pin	3	KH325P	88	60081960	Switch board	1
KH325P	27	60081902	Ring	1	KH325P	89	60081961	Screw ST4.2x16	2
KH325P	28	60081903	Ring spring	1	KH325P	90	60081962	Brush holder torsion spring	2
KH325P	29	60081904	Ring spring	1	KH325P	91	60081963	Carbon brush frame	1
KH325P	30	60081905	Hammer rod sleeve	1	KH325P	92	60081964	Carbon brush(pair)	1
KH325P	31	60081906	O ring	1	KH325P	93	60081965	Coil spring	2
KH325P	32	60081907	Knob	1	KH325P	94	60081966	Handle cover	1
KH325P	33	60081908	Spring	1	KH325P	95	60081967	Screw ST4.2x22	1
KH325P	34	60081909	Shifting stall knob	1	KH325P	96	60081968	Switch	1
KH325P	35	60081910	O ring	1	KH325P	97	60081969	Cord guard	1
KH325P	37	60081911	O ring	1	KH325P	98	60081970	Ball	1
KH325P	38	60081912	Sleeve	1	KH325P	99	60081971	Power cord	1
KH325P	39	60081913	Retaining ring	1	KH325P	100	60081972	Grip spring	1
KH325P	40	60081914	Piston	1	KH325P	101	60081973	T bolt	1
KH325P	41	60081915	O ring	1	KH325P	102	60081974	Grip base	1
KH325P	42	60081916	Aluminum cylinder	1	KH325P	103	60081975	Depth guage	1
KH325P	43	60081917	Gasket	2	KH325P	104	60081976	Bracket small knob	1
KH325P	44	60081918	Pin	1	KH325P	105	60081977	handle	1
KH325P	45	60081919	Stents bushing	1	KH325P	107	60081978	Connection wire 70mm	2
KH325P	46	60081920	O ring	1	KH325P	108	60081979	Tap adjusting component	1
KH325P	47	60081921	Aluminum bracket	1	KH325P	109	60081980	Trip component	1
KH325P	48	60081922	O ring	1	KH325P	110	60081981	Middle shaft component	1
KH325P	49	60081923	Needle bearing KG0709	1	KH325P	111	60081982	Fork component	1
KH325P	50	60081924	Gasket	1	KH325P	112	60081983	Bracket component	1
KH325P	51	60081925	Screw ST4.2x12	1	KH325P	113	60081984	Rotor set	1
KH325P	52	60081926	Middle shaft	1	KH325P	114	60081985	Auxiliary handle component	1
KH325P	53	60081927	Bearing 699	1	KH325P	115	60081986	Washer	1
KH325P	54	60081928	Screw M4x12	2	KH325P	116	60081987	Wool rope	1
KH325P	56	60081929	Screw M5x12	2	KH325P	117	60081988	Wool rope	2
KH325P	57	60081930	Spring washer 5	2					
KH325P	58	60081931	Rocker bearing plate	1					
KH325P	59	60081932	Rocker bearing	1					
KH325P	60	60081933	Needle bearing 151814	1					
KH325P	61	60081934	Needle bearing	1					

Kress



KH325P



Illustration

